Utilize CL0084,CL0085,CL0206 to create your own patch cord

Here you need the following tools. CableCreation CL0084(ratcheting tool),



CL0085(crimping tool),



CLO206(modular plug with black hood) (Note: Since it is easy to find a white hook, you would find it is a white hook, we just take the following steps for your reference.)



Step 1: Cut the jacket of Cat5e/6/7 cable and Put the hook connector on the cable



Step 2: Array the T568B wiring (You can also choose T568A if you need)

TIA/EIA-568-B.1-2001 T568A Wiring

| Pin | Pair | Wire | Color |
|-----|------|------|--------------|
| 1 | 3 | 1 | white/green |
| 2 | 3 | 2 | green |
| 3 | 2 | 1 | white/orange |
| 4 | 1 | 2 | 1 blue |
| 5 | 1 | 1 | white/blue |
| 6 | 2 | 2 | orange |
| 7 | 4 | 1 | white/brown |
| 8 | 4 | 2 | o brown |

(refer WIKIPEDIA

https://en.wikipedia.org/wiki/Category_5_cable)


TIA/EIA-568-B.1-2001 T568B Wiring[2]

| Pin | Pair | Wire | Color |
|-----|------|------|--------------|
| 1 | 2 | 1 | white/orange |
| 2 | 2 | 2 | orange |
| 3 | 3 | 1 | white/green |
| 4 | 1 | 2 | 1 blue |
| 5 | 1 | 1 | white/blue |
| 6 | 3 | 2 | green |
| 7 | 4 | 1 | white/brown |
| 8 | 4 | 2 | 1 brown |

(refer WIKIPEDIA

https://en.wikipedia.org/wiki/Category_5_cable)

Step 3: Wear the wire into the transparent cover





Step 4: Connect the hook connector and RJ45 plug together





Step 5:

5.1 Use the crimp tool to press the RJ45 plug



5.2 Use ratcheting tool to make the metal hook to connect the drain wire ,here I attach a photo for your reference.



Step 6: Wear the hook at the end of RJ45 connect, it's done!



Any more questions, you can contact with us at support@cablecreation.com

CableCreation Support Team